




4 SEATER ROUND (TWO PARTS)



3XL SEATER ROUND (TWO PARTS)



4 SEATER (TWO PARTS)



strona/page/Seite 2



SD M8x60
F x1



M8x16
G x1



L-5
H x1




8,5x22
I x3




M8x40
J x2

strona/page/Seite 3-4





no 153




no 154C



no 141A



WSI M6x25
A x4



US 5x35
B x4



L-4
C x1




φ45x3
D x2




φ30x2
E x6

strona/page/Seite 5



no 150A



US 5x35
B x4



WS M6x25
K x16




WS M6x35
L x4




φ20x2
M x6


1



2




3




2


4





5



6




7




4



8






9



5




11




7

12



13



Zachowaj instrukcję / Please keep instructions / Bewahren Sie die Anleitung / Merci de garder l'instruction